

Elevator Button Covers

Elevator Button Covers

These clear plastic button covers turn high-traffic public elevator buttons into continuously self-cleaning surfaces. Just peel and stick. Sold in sheets of 25 buttons. Includes NanoSeptic label to inform people that the buttons are self-cleaning.



Touchscreen Film

Clear Film for Touchscreens

From restaurant checkout to hospital and airline kiosks, this NanoSeptic film turns any touchscreen into a continuously self-cleaning surface. Low tack adhesive provides a more secure installation than traditional static cling. Can be cut to fit any size screen. The touchscreen shown has a label identifying the screen as a NanoSeptic surface. This label is included in all clear film orders.

Note: This film is intentionally 99% clear. It may have small bubbles after installing. This will not affect the operation of the touchscreen.



Surface Wraps for Doors and Elevator Handrails



Railing and Push Bar Wraps

These wraps are durable and easy to apply and replace – just peel and stick. Perfect for horizontal tubular railings or door push bars. Available in green leaf or brushed aluminum (pictured below) design.

